




H: 6U = 370.00 mm 9U = 503.35 mm 12U = 636.70 mm 15U = 770.05 mm 18U = 903.40 mm




Right




Front (with door)




Left



Front (without door)



Mounting dimension



1	Front glass door
2	Side panels
3	Top Cover (with fan vents)
4	Wall mounting bracket
5	Back Panel (optional)
6	Frame (front & rear)
7	Cable entry cover
8	Bottom cover
9	Mounting Angle
10	Mounting Profile
11	M8 x 12 Hex screws
12	M4 x 8 Self-tapping screws
13	M6 x 12 Screws and washers

M6 Screws and cage nuts

Grounding post

Flat-Packed Wall-Box Assembly Instructions

Screw list

	Α	В	С	D
Туре	Philips head self- tapping screws	Philips head screws & flange nuts	Hex socket cup screws & flange nuts	Philips head screws & cage nuts
Screw Spec.	M4 x 8	M6 x 12	M8 x 12	M6 x 12
Quantity (pcs)	10	8	16	20
Usage	Cable entry, rear panel	Mounting rails	Front & rear frames, top & bottom covers	Installation Screw sets for your devices

Parts list

		T		
A1	A2	A3	B1	C1
A1-2				, es
Top & bottom cover	Front and rear frame	Side bar	Mounting profile	Side panel
D1	D2	E1	E2	
Rear panel	Front door	Small round lock	Cable entry panel	

Assembly Instructions

1	2	3	4
Bottom cover, front & rear frames	Fix the front & rear frame to the bottom cover using type C screws	Side bar x 4	Install side bars using type C screws onto top & bottom frame
5	6	7	8
A1-2	Fix top cover to the	1 1	Install mounting
Top cover	front and rear frames using type C screws.	Mounting profile x 4 rails	profiles using type B screws
9	10	11	12
E2			
Fix top & bottom cable entry covers and rear panel using A type screws	Fix side panel x 2	Join front door with hinges	Finish assembly